



#### Painting Instructions for 4080 Live Well Slab

Kimble Colors needed: 750 Bisque Primer, 717 Mushroom, 763 Antique Media, 713 Primrose, 710 Sunshine, 711 Sapphire, 707 Evergreen, 700 White, 761 Perfect Matte Spray, 902 Black, 900 White

Kimble IT Brush Kit, detail brushes & soft paper towels

Use a large soft brush to basecoat the bisque with 750 Bisque Primer. Working in small areas apply 717 Mushroom and pat back with a soft paper towel and 763 Antique Media to antique the piece. Use a large soft natural hair filbert to apply 713 Primrose to the outer 2" rim of the rock. Wipe the color to blend using a soft paper towel and 763 Antique Media. Use the same technique to accent the center of the rock with 710 Sunshine. Blend the colors together. Use brushes of appropriate sizes to apply and pat back the following colors on the following areas: Hibiscus-713 Primrose, Small Flowers-710 Sunshine, Snapdragons-711 Sapphire, Leaves-707 Evergreen, Butterfly-710 Sapphire mixed with 700 White. Allow the color to dry completely and spray with 761 Perfect Matte Spray. Paint the edges of the butterfly and lettering with 902 black. Paint the flower centers and dots on butterfly with 900 White.